

## **Roamsafe Door Lock**

### **Operation.**

- The Whitco lock provided with our safety doors are a two stage lock.
- When the door is closed you may lock the door by turning the key or the lock snip on the inside.
- Locking the snip on the inside also means it may be unlocked by the snip again not requiring the key.
- We always suggest as an extra precaution locking the door with the key as this disengages the snip and you may only unlock the door with the key again.
- Always leave the key in a well known and safe spot as you will need to use the key to unlock the door, in case of an emergency vehicle evacuation.

## **Roamsafe Door Keeper**

### **Operation.**

- To operate your main door and safety door as one the switch on your keeper must be in the up position (this procedure is reversed on left hand lock doors).
- In order to lock your safety door the switch must be in the horizontal position.
- This is to allow you to enjoy the benefits of ease of use when on the road and also in and out of your vehicle, eliminating having to open and close two doors.